

Fitting Instructions: SPF2601K



Contents: Each kit contains 2 x rear toe control arm inner bushes and 2 x offset steel tubes

Fitting: Please read the complete instructions before commencing any work.

1. SPE recommend that all work be carried out by a qualified technician.
2. It is recommended to measure wheel alignment settings prior to fitment.
3. Raise the vehicle and support the vehicle on safety stands.
4. Remove rear toe-control arm and remove inner bushes from the arm.
5. Fit new SPF2601K bushes to the arm.
6. Fit new SPF2601K tubes, taking care of the orientation of the off-set hole.

To reduce bump steer, position the tubes with the holes off-set down.
(Recommended, see picture below). To increase bump steer, position the tubes with the holes offset up.



7. Re-fit toe-control arm and tighten all fittings.
8. Lower the vehicle.
9. Test drive the vehicle and check tension on all fasteners.
10. Measure wheel alignment and adjust as required.
11. Check & re-tension all fittings again after 100 miles but no more than 200 miles.